

Introduction to WANs

Objectives

After completing this chapter, you should be able to answer the following questions:

- How does the Cisco enterprise architecture provide integrated services over an enterprise network?
- What are the key WAN technology concepts?
- What appropriate WAN technologies are used to meet different enterprise business requirements?

Key Terms

This chapter uses the following key terms. You can find the definitions in the glossary at the end of the book.

wide-area network (WAN) page 3

enterprise network page 3

data communications page 3

transactions page 5

voice over IP (VoIP) page 6

broadband page 6

teleworkers page 11

wiring closets page 11

backbone page 12

metropolitan-area network (MAN) page 15

Frame Relay page 18

Asynchronous Transfer Mode (ATM) page 18

High-Level Data Link Control (HDLC) page 18

Customer Premises Equipment (CPE) page 19

channel page 19

Data Communications Equipment (DCE) page 19

Data Terminal Equipment (DTE) page 19

local loop page 19

cable page 19

demarcation point page 19

central office (CO) page 19

communications lines page 19

modem page 20

T1 page 20

T3 page 20

channel service unit (CSU) page 20

data service unit (DSU) page 20

T-carrier page 20

access server page 21

X.25 page 21

public switched telephone network (PSTN) page 21

Integrated Services Digital Network (ISDN)
page 21

point of presence (POP) page 21

core router page 21

High-Speed Serial Interface (HSSI) page 22

Point-to-Point Protocol (PPP) page 24

circuit page 26

time-division multiplexing (TDM) page 26

circuit-switching page 27

packet switching page 27

packet-switched network page 27

connectionless page 27

connection-oriented page 27

Data Link Connection Identifiers (DLCI) page 27

virtual circuit (VC) page 27

permanent virtual circuit (PVC) page 28

switched virtual circuit (SVC) page 28

leased line page 29

telephony page 33

bearer (B) channels page 33

signaling page 33

delta channel page 33

Basic Rate Interface (BRI) page 33

Primary Rate Interface (PRI) page 34

synchronization page 34

E1 page 34

J1 page 34

call setup time page 34

cell page 38

coaxial cable page 39

cable television 39

headend 39

Microwave 40

firewall 42

When an enterprise grows to include branch offices, e-commerce services, or global operations, a single local-area network (LAN) is no longer sufficient to meet its business requirements. *Wide-area network (WAN)* access has become essential for larger businesses today.

A variety of WAN technologies meet the different needs of businesses, and there are many ways to scale the network. Adding WAN access introduces other considerations, such as network security and address management. Consequently, designing a WAN and choosing the correct carrier network services is not a simple matter.

In this chapter, you will begin exploring some of the options available for designing enterprise WANs, the technologies available to implement them, and the terminology used to discuss them. You will learn about selecting the appropriate WAN technologies, services, and devices to meet the changing business requirements of an evolving enterprise. The activities and labs confirm and reinforce your learning.

After completing this chapter, you will be able to identify and describe the appropriate WAN technologies to enable integrated WAN services over a multilocation *enterprise network*.


Introducing Wide-Area Networks (WANs)

One way to categorize networks is to divide them into local-area networks (LAN) and wide-area networks (WAN). LANs typically are connected workstations, printers, and other devices within a limited geographic area such as a building. All the devices in the LAN are under the common administration of the owner of that LAN, such as a company or an educational institution. Most LANs today are Ethernet LANs.

WANs are networks that span a larger geographic area and usually require the services of a common carrier. Examples of WAN technologies and protocols include Frame Relay, ATM, and DSL.

What Is a WAN?

A WAN is a *data communications* network that operates beyond the geographic scope of a LAN. Figure 1-1 shows the relative location of a LAN and WAN.

Figure 1-1 WAN Location

WANs differ from LANs in several ways. Whereas a LAN connects computers, peripherals, and other devices in a single building or other small geographic area, a WAN allows the transmission of data across greater geographic distances. In addition, an enterprise must subscribe to a WAN service provider to use WAN carrier network services. LANs typically are owned by the company or organization that uses them.

WANs use facilities provided by a service provider, or carrier, such as a telephone or cable company, to connect the locations of an organization to each other, to locations of other organizations, to external services, and to remote users. WANs provide network capabilities to support a variety of mission-critical traffic such as voice, video, and data.

Here are the three major characteristics of WANs:

- WANs generally connect devices that are separated by a broader geographic area than can be served by a LAN.
- WANs use the services of carriers, such as telephone companies, cable companies, satellite systems, and network providers.
- WANs use serial connections of various types to provide access to bandwidth over large geographic areas.

Why Are WANs Necessary?

LAN technologies provide both speed and cost efficiency for the transmission of data in organizations over relatively small geographic areas. However, other business needs require communication among remote sites, including the following:

- People in the regional or branch offices of an organization need to be able to communicate and share resources with the central site.
- Organizations often want to share information with other organizations across large distances. For example, software manufacturers routinely communicate product and promotion information to distributors that sell their products to end users.
- Employees who frequently travel on company business need to access information that resides on their corporate networks.

In addition, home computer users need to send and receive data across increasingly larger distances. Here are some examples:

- It is now common in many households for consumers to communicate with banks, stores, and a variety of providers of goods and services via computers.
- Students do research for classes by accessing library catalogs and publications located in other parts of their country and in other parts of the world.

Because it is obviously not feasible to connect computers across a country or around the world in the same way that they are connected in a LAN with cables, different technologies have evolved to support this need. The Internet has become and continues to be an inexpensive alternative for WAN connectivity. New technologies are available to businesses to provide security and privacy for their Internet communications and *transactions*. WANs used by themselves, or in concert with the Internet, allow organizations and individuals to meet their wide-area communication needs.

The Evolving Enterprise

As companies grow, they hire more employees, open branch offices, and expand into global markets. These changes also influence companies' requirements for integrated services and drive their network requirements. This section explores how company networks evolve to accommodate companies' changing business requirements.

Businesses and Their Networks

Every business is unique. How an organization grows depends on many factors, such as the type of products or services the business sells, the owners' management philosophy, and the economic climate of the country in which the business operates.

In slow economic times, many businesses focus on increasing their profitability by improving the efficiency of the existing operations, increasing employee productivity, and lowering operating costs. Establishing and managing networks can represent significant installation and operating expenses. To justify such a large expense, companies expect their networks to perform optimally and to be able to deliver an ever-increasing array of services and applications to support productivity and profitability.

To illustrate, we'll use a fictitious company called Span Engineering as an example. You'll watch how its network requirements change as the company grows from a small local business into a global enterprise.

Small Office (Single LAN)

Span Engineering, an environmental consulting firm, has developed a special process for converting household waste into electricity. It is developing a small pilot project for a municipal government in its local area. The company, which has been in business for four years, has grown to include 15 employees: six engineers, four computer-aided drawing (CAD) designers, two senior partners, a receptionist, and two office assistants.

Span Engineering's management is hoping that the company will have full-scale projects after the pilot project successfully demonstrates the feasibility of its process. Until then, the company must manage its costs carefully.


For its small office, shown in Figure 1-2, Span Engineering uses a single LAN to share information between computers and to share peripherals, such as a printer, a large-scale plotter (to print engineering drawings), and fax equipment. The company recently upgraded its LAN to provide inexpensive *voice over IP (VoIP)* service to save on the costs of separate phone lines for its employees.

The company connects to the Internet through a common *broadband* service called Digital Subscriber Line (DSL), which is supplied by the local telephone service provider. With so few employees, bandwidth is not a significant problem.

The company cannot afford in-house information technology (IT) support staff, so it uses support services purchased from the same service provider. The company also uses a hosting service rather than purchasing and operating its own FTP and e-mail servers.

Campus (Multiple LANs)


Five years later, Span Engineering has grown rapidly. As the owners had hoped, the company was contracted to design and implement a full-sized waste conversion facility soon after the successful implementation of their first pilot plant. Since then, other projects have also been won in neighboring municipalities and in other parts of the country.

Figure 1-2 Small-Office LAN

To handle the additional workload, the business has hired more staff and leased more office space. It is now a small to medium-sized business with several hundred employees. Many projects are being developed at the same time, and each requires a project manager and support staff. The company has organized itself into functional departments, with each department having its own organizational team. To meet its growing needs, the company has moved into several floors of a larger office building.

As the business has expanded, the network has also grown. Instead of a single small LAN, the network now consists of several subnetworks, each devoted to a different department. For example, all the engineering staff are on one LAN, and the marketing staff is on another LAN. These multiple LANs are joined to create a company-wide network, or campus, which spans several floors of the building. Figure 1-3 shows Span Engineering's expanded campus LAN.

The business now has in-house IT staff to support and maintain the network. The network includes servers for e-mail, data transfer and file storage, web-based productivity tools, and applications. The network includes a company intranet to provide in-house documents and information to employees. In addition, the company has an extranet that provides project information only to designated customers.


Figure 1-3 Campus (Multiple LANs)

Branch (WAN)

Another five years later, Span Engineering has been so successful with its patented process that demand for its services has skyrocketed. New projects are now being built in other cities. To manage those projects, the company has opened small branch offices closer to the project sites.

This situation presents new challenges to the IT team. To manage the delivery of information and services throughout the company, Span Engineering now has a data center, which houses the company's various databases and servers. To ensure that all parts of the business can access the same services and applications regardless of where the offices are located, the company now needs to implement a WAN.

For its branch and regional offices that are in nearby cities, the company decides to use private dedicated lines through its local service provider, as shown in Figure 1-4. However, for the offices that are located in other countries, the Internet is now an attractive WAN connection option. Although connecting offices through the Internet is economical, it introduces security and privacy issues that the IT team must address.

Figure 1-4 Branch (WAN)

Distributed (Global)

Span Engineering has now been in business for 20 years and has grown to thousands of employees distributed in offices worldwide. The cost of the network and its related services is a significant expense. The company is looking to provide its employees with the best network services at the lowest cost. Optimized network services would allow each employee to work at high efficiency.

To increase profitability, Span Engineering needs to reduce its operating expenses. It has relocated some of its office facilities to less expensive areas. The company is also encouraging teleworking and virtual teams. Web-based applications—including web conferencing, e-learning, and online collaboration tools—are being used to increase productivity and reduce costs. Site-to-site and remote-access Virtual Private Networks (VPN) enable the company to use the Internet to connect easily and securely with employees and facilities around the world. To meet these requirements, the network must provide the necessary converged services and secure Internet WAN connectivity to remote offices and individuals. Figure 1-5 shows SPAN Engineering's new distributed or global network.


The Evolving Network Model

The hierarchical network model is a framework that helps you visualize and design networks. Several variations of this model exist, and it can be adapted for specific implementations.

The Hierarchical Design Model

Figure 1-6 shows the hierarchical network model, which is a useful high-level tool for designing a reliable network infrastructure. It provides a modular view of a network, making it easier to design and build a scalable network. The figure conceptually displays the model and identifies its major responsibilities.

Figure 1-6 Hierarchical Network Model



The Hierarchical Network Model


As you may recall from *CCNA Exploration: LAN Switching and Wireless*, the hierarchical network model divides a network into three layers:

- The access layer grants user access to network devices. In a network campus, the access layer generally incorporates switched LAN devices with ports that provide connectivity to workstations and servers. In the WAN environment, it may give *teleworkers* or remote sites access to the corporate network across WAN technology.
- The distribution layer aggregates the *wiring closets*, using switches to segment workgroups and isolate network problems in a campus environment. Similarly, the distribution layer aggregates WAN connections at the edge of the campus and provides policy-based connectivity.

- The core layer (also called the backbone) is a high-speed *backbone* that is designed to switch packets as fast as possible. Because the core is critical for connectivity, it must provide a high level of availability and adapt to changes very quickly. It also provides scalability and fast convergence.

Figure 1-7 represents the Hierarchical Network Model in campus environments. The Hierarchical Network Model provides a modular framework that allows flexibility in network design and facilitates ease of implementation and troubleshooting in the infrastructure. However, it is important to understand that the network infrastructure is only the foundation of a comprehensive architecture.

Figure 1-7 Hierarchical Network Model in Campus Environments




Networking technologies have advanced considerably in recent years, resulting in networks that are increasingly intelligent. The current network elements are more aware of traffic characteristics and can be configured to deliver specialized services based on such things as the types of data they carry, the data's priority, and even the security needs. Although most of these various infrastructure services are outside the scope of this course, it is important to understand that they influence network design. The next sections explore the Cisco Enterprise Architecture, which expands on the hierarchical model by making use of network intelligence to address the network infrastructure.

The Enterprise Architecture

As described earlier, different businesses need different types of networks, depending on how the business is organized and its business goals. Unfortunately, all too often networks grow in a haphazard way as new components are added in response to immediate needs. Over time, those networks become complex and expensive to manage. Because the network is a mixture of newer and older technologies, it can be difficult to support and maintain. Outages and poor performance are a constant source of trouble for network administrators.

To help prevent this situation, Cisco has developed a recommended architecture called the Cisco Enterprise Architecture. It has relevance to the different stages of a business's growth, as shown in Figure 1-8. This architecture is designed to give network planners a road map for network growth as the business moves through different stages. By following the suggested road map, IT managers can plan for future network upgrades that will integrate seamlessly into the existing network and support the ever-growing need for services.

Figure 1-8 Cisco Enterprise Architecture




The Cisco Enterprise Architecture consists of modules representing focused views that target each place in the network. Each module has a distinct network infrastructure with services and network applications that extend across the modules. The following are some of the modules within the architecture that are relevant to the Span Engineering scenario described earlier:

- Enterprise Campus Architecture
- Enterprise Branch Architecture
- Enterprise Data Center Architecture
- Enterprise Teleworker Architecture

Figure 1-9 shows the Cisco Enterprise Architecture, which consists of modules representing focused views that target each place in the network. Each module has a distinct network infrastructure with services and network applications that extend across the modules.

Figure 1-9 Modules of the Enterprise Architecture



The Cisco Enterprise Architecture includes the following modules, each of which is described in greater detail in the following sections:

- Enterprise Campus Architecture

- Enterprise Edge Architecture
- Enterprise Branch Architecture
- Enterprise Data Center Architecture
- Enterprise Teleworker Architecture

Enterprise Campus Architecture

A campus network is a building or group of buildings connected into one enterprise network that consists of many LANs. A campus generally is limited to a fixed geographic area, but it can span several neighboring buildings, such as an industrial complex or business park environment. In the Span Engineering example, the campus spans multiple floors of the same building.

The Enterprise Campus Architecture describes the recommended methods to create a scalable network while addressing the needs of campus-style business operations. The architecture is modular and can easily expand to include additional campus buildings or floors as the enterprise grows. The Enterprise Campus Architecture, as illustrated in Figure 1-9, is composed of four submodules:

- The building access contains end-user workstations, IP phones, and Layer 2 access switches that connect devices to the building distribution submodule.
- The building distribution provides aggregation of building access devices, often using Layer 3 switching. This submodule performs routing, quality control, and access control.
- The campus core provides redundant and fast-converging connectivity between buildings and the server farm and enterprise edge.
- The server farm contains e-mail and corporate servers providing application, file, print, e-mail, and Domain Name System (DNS) services to internal users.

The enterprise campus module describes the connections between users, the campus network, the server farm, and the Enterprise Edge modules.

Enterprise Edge Architecture

This module, as illustrated in Figure 1-9, often functions as a liaison between the campus module and the other modules in the Enterprise Architecture. It offers connectivity to voice, video, and data services outside the enterprise. It enables the enterprise to use Internet and partner resources and provide resources for its customers. The Enterprise WAN and *metropolitan-area network (MAN)* Architecture, which the technologies covered later in this course are relevant to, are considered part of this module.

The enterprise edge aggregates the connectivity from the various functional areas at the enterprise edge (e-commerce, Internet connectivity, and VPNs) and routes the traffic into the campus core submodule.

Enterprise Branch Architecture

This module, as illustrated in Figure 1-9, allows businesses to extend the applications and services found at the campus to thousands of remote locations and users or to a small group of branches. Much of this course focuses on the technologies that are often implemented in this module.

Enterprise Data Center Architecture

Data centers provide management for many data systems that are vital to modern business operations. Employees, partners, and customers rely on data and resources in the data center to effectively create, collaborate, and interact. Over the last decade, the rise of Internet and web-based technologies has made the data center more important than ever, improving productivity, enhancing business processes, and accelerating change.


The enterprise data center, as illustrated in Figure 1-9, manages and maintains centralized data systems for the entire enterprise.

Enterprise Teleworker Architecture

Many businesses today offer a flexible work environment to their employees, allowing them to telecommute from home offices. To telecommute is to leverage the network resources of the enterprise from home. The teleworker module, as illustrated in Figure 1-9, recommends that connections from home using broadband services such as cable modem or DSL connect to the Internet and from there to the corporate network. Because the Internet introduces significant security risks to businesses, special measures need to be taken to ensure that teleworker communications are secure and private.

The enterprise teleworker module connects individual employees to network resources remotely, typically from their homes.

Figure 1-10 shows how all the Enterprise Architecture modules can be used to build a business network topology.

Figure 1-10 Sample Enterprise Architecture Topology


WAN Technology Concepts

This section discusses the physical and data link layer concepts of wide-area networks, including an introduction to some of the standards and protocols.

WAN Technology Overview

A variety of protocols and technologies are used in wide-area networks. Some of these services, such as HDLC and Frame Relay, are explained in more detail later in this book.

As described in relation to the OSI reference model, WAN operations focus primarily on Layer 1 and Layer 2, as shown in Figure 1-11. WAN access standards typically describe both physical layer delivery methods and data link layer requirements, including physical addressing, flow control, and encapsulation. WAN access standards are defined and managed by a number of recognized authorities, including the International Organization for Standardization (ISO), the Telecommunication Industry Association (TIA), and the Electronic Industries Alliance (EIA).

Figure 1-11 OSI and WAN Services

As highlighted in Figure 1-11, the physical layer (OSI Layer 1) protocols describe how to provide electrical, mechanical, operational, and functional connections to the services of a communications service provider.

The data link layer (OSI Layer 2) protocols define how data is encapsulated for transmission toward a remote location and the mechanisms for transferring the resulting frames. A variety of technologies are used, such as *Frame Relay* and *Asynchronous Transfer Mode (ATM)*. Some of these protocols use the same basic framing mechanism, *High-Level Data Link Control (HDLC)*, an ISO standard, or one of its subsets or variants.

WAN Physical Layer Concepts

The WAN physical layer includes several devices and terms specific to wide-area networks, as described in the following sections.


WAN Physical Layer Terminology

One primary difference between a WAN and a LAN is that for a company or organization to use WAN carrier network services, it must subscribe to an outside WAN service provider. A WAN uses data links provided by carrier services to access or connect the locations of an

organization to each other, to locations of other organizations, to external services, and to remote users. The WAN access physical layer describes the physical connection between the company network and the service provider network.

Figure 1-12 illustrates the terminology commonly used to describe physical WAN connections, as described in further detail in the following list:

- **Customer Premises Equipment (CPE):** The devices and inside wiring located at the premises of the subscriber, connected with a telecommunication *channel* of a carrier. The subscriber either owns or leases the CPE. A subscriber, in this context, is a company that arranges for WAN services from a service provider or carrier.
- **Data Communications Equipment (DCE):** Also called data circuit-terminating equipment, the DCE consists of devices that put data on the local loop. The DCE primarily provides an interface to connect subscribers to a communication link on the WAN cloud.
- **Data Terminal Equipment (DTE):** The customer devices that pass the data from a customer network or host computer for transmission over the WAN. The DTE connects to the local loop through the DCE.
- **Local loop:** The copper or fiber *cable* that connects the CPE at the subscriber site to the central office (CO) of the service provider. The local loop is sometimes called the “last mile.”
- **Demarcation point:** A point established in a building or complex to separate customer equipment from service provider equipment. Physically, the demarcation point is the cabling junction box, located on the customer premises, that connects the CPE wiring to the local loop. It is usually placed for easy access by a technician. The demarcation point is the place where the responsibility for the connection changes from the user to the service provider. This is very important, because when problems arise, it is necessary to determine whether the user or the service provider is responsible for troubleshooting or repair.
- **Central office (CO):** A local service provider facility or building where local cables link to long-haul, all-digital, fiber-optic *communications lines* through a system of switches and other equipment.

Figure 1-12 WAN Physical Layer Terminology

WAN Devices


WANs use numerous types of devices that are specific to WAN environments:

- **Modem:** Modulates an analog carrier signal to encode digital information, and also demodulates the carrier signal to decode the transmitted information. A voiceband modem converts the digital signals produced by a computer into voice frequencies that can be transmitted over the analog lines of the public telephone network. On the other side of the connection, another modem converts the sounds back into a digital signal for input to a computer or network connection. Faster modems, such as cable modems and DSL modems, transmit using higher broadband frequencies.
- **CSU/DSU:** Digital lines, such as *T1* and *T3* carrier lines, require a *channel service unit (CSU)* and a *data service unit (DSU)*. The two are often combined into a single piece of equipment, called the CSU/DSU. The CSU provides termination for the digital signal and ensures connection integrity through error correction and line monitoring. The DSU converts the *T-carrier* line frames into frames that the LAN can interpret and vice versa.

- **Access server:** Concentrates dial-in and dial-out user communications. An access server may have a mixture of analog and digital interfaces and support hundreds of simultaneous users.
- **WAN switch:** A multiport internetworking device used in carrier networks. These devices typically switch traffic such as Frame Relay, ATM, or *X.25* and operate at the data link layer of the OSI reference model. *Public switched telephone network (PSTN)* switches may also be used within the cloud for circuit-switched connections such as *Integrated Services Digital Network (ISDN)* or analog dialup.
- **Router:** Provides internetworking and WAN access interface ports that are used to connect to the service provider network. These interfaces may be serial connections or other WAN interfaces. With some types of WAN interfaces, an external device such as a DSU/CSU or modem (analog, cable, or DSL) is required to connect the router to the service provider's local *point of presence (POP)*.
- **Core router:** A router that resides within the middle or backbone of the WAN rather than at its periphery. To fulfill this role, a router must be able to support multiple telecommunications interfaces of the highest speed in use in the WAN core, and it must be able to forward IP packets at full speed on all those interfaces. The router must also support the routing protocols being used in the core.

Figure 1-13 shows the location of each device.

Figure 1-13 WAN Devices



WAN Physical Layer Standards

WAN physical-layer protocols describe how to provide electrical, mechanical, operational, and functional connections for WAN services. The WAN physical layer also describes the interface between the DTE and DCE.


The DTE/DCE interface uses various physical layer protocols:

- **EIA/TIA-232:** This protocol allows signal speeds of up to 64 kbps on a 25-pin D-connector over short distances. It was formerly known as RS-232. The ITU-T V.24 specification is effectively the same.
- **EIA/TIA-449/530:** This protocol is a faster (up to 2 Mbps) version of EIA/TIA-232. It uses a 36-pin D-connector and is capable of longer cable runs. Several versions exist. This standard is also known as RS-422 and RS-423.
- **EIA/TIA-612/613:** This standard describes the *High-Speed Serial Interface (HSSI)* protocol, which provides access to services up to 52 Mbps on a 60-pin D-connector.
- **V.35:** This is the ITU-T standard for synchronous communications between a network access device and a packet network. Originally specified to support data rates of 48 kbps, it now supports speeds of up to 2.048 Mbps using a 34-pin rectangular connector.
- **X.21:** This protocol is an ITU-T standard for synchronous digital communications. It uses a 15-pin D-connector.

These protocols establish the codes and electrical parameters the devices use to communicate with each other. Choosing a protocol is largely determined by the service provider’s method of facilitation.

Figure 1-14 illustrates the types of cable connectors associated with each physical layer protocol.

Figure 1-14 WAN Cable Connectors




WAN Data Link Layer Concepts

In addition to physical layer devices, WANs require data link layer protocols to establish the link across the communication line from the sending to the receiving device. This section describes the common data link protocols that are used in today's enterprise networks to implement WAN connections.

Data Link Protocols

Data link layer protocols define how data is encapsulated for transmission to remote sites and the mechanisms for transferring the resulting frames. A variety of technologies are used, such as ISDN, Frame Relay, or ATM, as shown in Figure 1-15. Many of these protocols use the same basic framing mechanism, HDLC, an ISO standard, or one of its subsets or variants. ATM is different from the others, because it uses small fixed-size cells of 53 bytes (48 bytes for data), unlike the other packet-switched technologies, which use variable-sized packets.

Figure 1-15 Data Link Layer Protocols



Protocol	Usage
Link Access Procedure Balanced (LAPB)	X.25
Link Access Procedure D Channel (LAPD)	ISDN D Channel
Link Access Procedure Frame (LAPF)	Frame Relay
High-Level Data Link Control (HDLC)	Cisco Default
Point-to-Point Protocol (PPP)	Serial WAN Switched Connections

The most common WAN data-link protocols are as follows:

- HDLC
- *Point-to-Point Protocol (PPP)*
- Frame Relay
- ATM

ISDN and X.25 are older data-link protocols that are less frequently used today. However, ISDN is still covered in this course because of its use when provisioning a VoIP network using PRI links. X.25 is mentioned to help explain the relevance of Frame Relay. As well, X.25 is still in use in developing countries where packet data networks (PDN) are used to transmit credit card and debit card transactions from retailers.

Note


Another data link layer protocol is Multiprotocol Label Switching (MPLS). MPLS is increasingly being deployed by service providers as an economical solution to carry circuit-switched as well as packet-switched network traffic. It can operate over any existing infrastructure, such as IP, Frame Relay, ATM, or Ethernet. It sits between Layer 2 and Layer 3 and is sometimes referred to as a Layer 2.5 protocol. MPLS is beyond the scope of this course, but it is covered on the CCNP: Implementing Secure Converged Wide Area Networks course.

WAN Encapsulation


Data from the network layer is passed to the data link layer for delivery on a physical link, which normally is point-to-point on a WAN connection. The data link layer builds a frame around the network layer data so that the necessary checks and controls can be applied. Each WAN connection type uses a Layer 2 protocol to encapsulate a packet while it is crossing the WAN link. To ensure that the correct encapsulation protocol is used, the Layer 2 encapsulation type used for each router serial interface must be configured. The choice of encapsulation protocols depends on the WAN technology and the equipment. HDLC was first proposed in 1979; for this reason, most framing protocols that were developed afterwards are based on it.

Figure 1-16 shows how WAN data link protocols encapsulate traffic.

Examining the header portion of an HDLC frame, shown in Figure 1-17, helps you identify common fields used by many WAN encapsulation protocols. The frame always starts and ends with an 8-bit Flag field. The bit pattern is 01111110. The Address field is not needed for WAN links, which are almost always point-to-point. The Address field is still present and may be 1 or 2 bytes long. The Control field is protocol-dependent, but it usually indicates whether the data is control information or network layer data. The Control field normally is 1 byte.

Figure 1-16 WAN Encapsulation

Network data is encapsulated in an HDLC frame.

Figure 1-17 WAN Frame Encapsulation Formats

A WAN header address field is usually a broadcast address on a point-to-point link. The control field identifies the data portion as either information or control. The protocol field identifies the intended layer 3 protocol (e.g., IP, IPX).

The Address and Control fields, as illustrated in Figure 1-17, are called the frame header. The encapsulated data follows the Control field. Then a frame check sequence (FCS) uses the cyclic redundancy check (CRC) mechanism to establish a 2- or 4-byte field.

Several types of WAN encapsulation formats exist, including subsets and proprietary versions of HDLC. Both PPP and the Cisco version of HDLC have an extra field in the header to identify the network layer protocol of the encapsulated data.

WAN Switching Concepts


WAN switched networks are categorized as either circuit-switched or packet-switched, as described in greater detail in the following sections.

Circuit Switching

A circuit-switched network is one that establishes a dedicated *circuit* (or channel) between nodes and terminals before the users may communicate.

As an example, Figure 1-18 shows that when a subscriber makes a telephone call, the dialed number is used to set switches in the exchanges along the call's route so that a continuous circuit exists from the caller to the called party. Because of the switching operation used to establish the circuit, the telephone system is called a circuit-switched network. If the telephones are replaced with modems, the switched circuit can carry computer data.

Figure 1-18 Circuit Switching



The internal path taken by the circuit between exchanges is shared by a number of conversations. *Time-division multiplexing (TDM)* gives each conversation a share of the connection in turn. TDM ensures that a fixed-capacity connection is made available to the subscriber.

If the circuit carries computer data, the usage of this fixed capacity may be inefficient. For example, if the circuit is used to access the Internet, a burst of activity occurs on the circuit while a web page is transferred. This could be followed by no activity while the user reads the page, and then another burst of activity while the next page is transferred. This variation in usage between none and maximum is typical of computer network traffic. Because the subscriber has sole use of the fixed-capacity allocation, switched circuits generally are an expensive way of moving data.

PSTN and ISDN are two types of *circuit-switching* technology that may be used to implement a WAN in an enterprise setting.

Packet Switching


In contrast to circuit switching, *packet switching* splits traffic data into packets that are routed over a shared network. Packet-switching networks do not require a circuit to be established, and they allow many pairs of nodes to communicate over the same channel.

The switches in a *packet-switched network* determine which link the packet must be sent on next from the addressing information in each packet. There are two approaches to this link determination:

- *Connectionless* systems, such as the Internet, carry full addressing information in each packet. Each switch must evaluate the address to determine where to send the packet.
- *Connection-oriented* systems predetermine a packet's route, and each packet only has to carry an identifier. In the case of Frame Relay, these are called *Data Link Connection Identifiers (DLCI)*. The switch determines the onward route by looking up the identifier in tables held in memory. The set of entries in the tables identifies a particular route or circuit through the system. If this circuit exists only while a packet travels through it, it is called a *virtual circuit (VC)*. A virtual circuit is a logical circuit between two network devices to help ensure reliable communications.

Because the internal links between the switches are shared between many users, the costs of packet switching are lower than those of circuit switching. Delays (latency) and variability of delay (jitter) are greater in packet-switched networks than in circuit-switched networks. This is because the links are shared, and packets must be entirely received at one switch before moving to the next. Despite the latency and jitter inherent in shared networks, modern technology allows satisfactory transport of voice and even video communications on these networks.

In Figure 1-19, Server A is sending data to Server B. Packets may not necessarily always take the same path to reach the destination. Each packet may take different routes to reach Server B.

Figure 1-19 Packet Switching

Virtual Circuits

Packet-switched networks may establish routes through the switches for particular end-to-end connections. These routes are called virtual circuits (VC). A VC is a logical circuit created within a shared network between two network devices. Two types of VCs exist:

- **Permanent virtual circuit (PVC):** A permanently established virtual circuit that consists of one mode: data transfer. PVCs are used in situations in which data transfer between devices is constant. PVCs decrease the bandwidth use associated with establishing and terminating VCs, but they increase costs because of constant virtual circuit availability. PVCs generally are configured by the service provider when an order is placed for service.
- **Switched virtual circuit (SVC):** A VC that is dynamically established on demand and terminated when transmission is complete. Communication over an SVC consists of three phases: circuit establishment, data transfer, and circuit termination. The establishment phase involves creating the VC between the source and destination devices, with SVC entries stored in lookup tables held in memory. Data transfer involves transmitting data between the devices over the VC, and the circuit termination phase involves tearing down the VC between the source and destination devices. SVCs are used in situations in which data transmission between devices is intermittent, largely to save costs. SVCs release the circuit when transmission is complete, which results in less expensive connection charges than those incurred by PVCs, which maintain constant virtual circuit availability.

Note

Virtual circuits are discussed in more detail in Chapter 3, “Frame Relay.”

Connecting to a Packet-Switched Network

To connect to a packet-switched network, a subscriber needs a local loop to the nearest location where the provider makes the service available. This is called the service’s point of presence (POP). Normally this is a dedicated leased line. This line is much shorter than a leased line connected directly between the subscriber locations. In addition, this one line to the POP can carry several VCs, allowing it to provide connections to multiple destinations. Because it is likely that not all the VCs require maximum demand simultaneously, the capacity of the *leased line* can be smaller than the sum of the individual VCs. Examples of packet- or cell-switched connections include

- X.25
- Frame Relay
- ATM

WAN Connection Options

This section covers various WAN connection options, including private dedicated links, private switched links, and public connection options using the Internet.

WAN Link Connection Options

Many options for implementing WAN solutions are currently available. They differ in technology, speed, and cost. Familiarity with these technologies is an important part of network design and evaluation:

Figure 1-20 provides a high-level view of the various WAN link connection options:

- **Private WAN connection options:** Private WAN connections include both dedicated and switched communication link options:
 - **Dedicated communication links:** When permanent dedicated connections are required, point-to-point lines are used with various capacities that are limited only by the underlying physical facilities and the willingness of users to pay for these dedicated lines. A point-to-point link provides a preestablished WAN communications path from the customer premises through the provider network to a remote destination. Point-to-point lines usually are leased from a carrier and are also called leased lines.


- **Switched communication links:** Switched communication links can be either circuit-switched or packet-switched:

Circuit-switched communication links: Circuit switching dynamically establishes a dedicated connection for voice or data between a sender and a receiver. Before communication can start, it is necessary to establish the connection through the service provider's network. Examples of circuit-switched communication links are analog dialup (PSTN) and ISDN.

Packet-switched communication links: Many WAN users do not make efficient use of the fixed bandwidth that is available with dedicated, switched, or permanent circuits, because the data flow fluctuates. Communications providers have data networks available to more appropriately service these users. In packet-switched networks, the data is transmitted in labeled frames, cells, or packets. Packet-switched communication links include Frame Relay, ATM, X.25, and Metro Ethernet.

- **Public WAN connection options:** Public connections use the global Internet infrastructure. Until recently, the Internet was not a viable networking option for many businesses because of the significant security risks and lack of adequate performance guarantees in an end-to-end Internet connection. With the development of VPN technology, however, the Internet is now an inexpensive and secure option for connecting to teleworkers and remote offices where performance guarantees are not critical. Internet WAN connection links are through broadband services such as DSL, cable modem, and broadband wireless, and they are combined with VPN technology to provide privacy across the Internet.

Figure 1-20 WAN Link Connection Options




Dedicated Connection Link Options

When permanent dedicated connections are required, a point-to-point link is used to provide a preestablished WAN communications path from the customer premises through the provider network to a remote destination.

Point-to-point lines usually are leased from a carrier and are called leased lines. Figure 1-21 shows a T3 and E3 circuit. This section describes how enterprises use leased lines to provide a dedicated WAN connection.

Figure 1-21 Leased Lines



Leased lines are available in different capacities. They generally are priced based on the bandwidth required and the distance between the two connected points.

Table 1-1 lists the available leased-line types and their bit-rate capacities.

Table 1-1 Leased-Line Types and Capacities

Line Type	Bit Rate Capacity	Line Type	Bit Rate Capacity
56	56 kbps	OC-9	466.56 Mbps
64	64 kbps	OC-12	622.08 Mbps
T1	1.544 Mbps	OC-18	933.12 Mbps
E1	2.048 Mbps	OC-24	1244.16 Mbps
J1	2.048 Mbps	OC-36	1866.24 Mbps
E3	34.064 Mbps	OC-48	2488.32 Mbps
T3	44.736 Mbps	OC-96	4976.64 Mbps
OC-1	51.84 Mbps	OC-192	9953.28 Mbps
OC-3	155.54 Mbps	OC-768	39,813.12 Mbps

Point-to-point links usually are more expensive than shared services such as Frame Relay. The cost of leased-line solutions can become significant when they are used to connect many sites over increasing distances. However, sometimes the benefits outweigh the cost of the leased line. The dedicated capacity removes latency and jitter between the endpoints. Constant availability is essential for some applications, such as VoIP and video over IP.

A router serial port is required for each leased-line connection. A CSU/DSU and the actual circuit from the service provider are also required.

Leased lines provide permanent dedicated capacity and are used extensively to build WANs. They have been the traditional connection of choice but have a number of disadvantages. Leased lines have a fixed capacity; however, WAN traffic is often variable, leaving some of the capacity unused. In addition, each endpoint needs a separate physical interface on the router, which increases equipment costs. Any changes to the leased line generally require a site visit by the carrier.

Circuit-Switched Connection Options


Circuit-switched networks establish a dedicated connection for voice or data between a sender and a receiver. Before any communications can begin, it is necessary to establish the connection through the service provider's network.

Analog Dialup

When intermittent, low-volume data transfers are needed, modems and analog dialed telephone lines provide low capacity and dedicated switched connections.

This section describes the pros and cons of using analog dialup connection options and describes the types of business scenarios that benefit most from this type of option. Figure 1-22 shows an analog dialup connection.

Figure 1-22 WAN Built with an Intermittent Connection Using a Modem and the Voice Telephone Network



Traditional *telephony* uses a copper cable, called the local loop, to connect the telephone handset in the subscriber premises to the CO. The signal on the local loop during a call is a continuously varying electronic signal that is a translation of the subscriber analog voice signal.

Traditional local loops can transport binary computer data through the voice telephone network using a modem. The modem modulates the binary data into an analog signal at the source and demodulates the analog signal into binary data at the destination. The physical characteristics of the local loop and its connection to the PSTN limit the signal's rate to less than 56 kbps.

For small businesses, these relatively low-speed dialup connections are adequate for the exchange of sales figures, prices, routine reports, and e-mail. Using automatic dialup at night or on weekends for large file transfers and data backup can take advantage of lower off-peak tariffs (line charges). Tariffs are based on the distance between the endpoints, time of day, and the call's duration.

The advantages of modem and analog lines are simplicity, availability, and low implementation cost. The disadvantages are the low data rates and a relatively long connection time. The dedicated circuit has little delay or jitter for point-to-point traffic, but voice or video traffic does not operate adequately at these low bit rates.

Integrated Services Digital Network

Integrated Services Digital Network (ISDN) is a circuit-switching technology that enables the local loop of a PSTN to carry digital signals, resulting in higher-capacity switched connections. ISDN changes the internal connections of the PSTN from carrying analog signals to time-division multiplexed (TDM) digital signals. TDM allows two or more signals or bit streams to be transferred as subchannels in one communication channel. The signals appear to transfer simultaneously, but physically they take turns on the channel. A data block of subchannel 1 is transmitted during time slot 1, subchannel 2 during time slot 2, and so on. One TDM frame consists of one time slot per subchannel. TDM is described in more detail in Chapter 2, "PPP."

ISDN turns the local loop into a TDM digital connection. This change enables the local loop to carry digital signals that result in higher-capacity switched connections. The connection uses 64-kbps *bearer (B) channels* to carry voice or data and a *signaling, delta channel* for call setup and other purposes.


There are two types of ISDN interfaces:

- **Basic Rate Interface (BRI)**: ISDN is intended for the home and small enterprise and provides two 64-kbps B channels and a 16-kbps D channel. The BRI D channel is designed for control and often is underused, because it has only two B channels to control. Therefore, some providers allow the D channel to carry data at low bit rates, such as X.25 connections at 9.6 kbps.

- Primary Rate Interface (PRI):** ISDN is also available for larger installations. PRI delivers 23 B channels with 64 kbps and one D channel with 64 kbps in North America, for a total bit rate of up to 1.544 Mbps. This includes some additional overhead for *synchronization*. In Europe, Australia, and other parts of the world, ISDN PRI provides 30 B channels and one D channel, for a total bit rate of up to 2.048 Mbps, including synchronization overhead. In North America, PRI corresponds to a T1 connection. The PRI rate of lines outside North America corresponds to an *E1* or *J1* connection.

Figure 1-23 illustrates the various differences between ISDN BRI and PRI lines.

Figure 1-23 ISDN Network Infrastructure and PRI/BRI Line Capacity



For WAN links, which require low bandwidth, the BRI ISDN can provide an ideal connection mechanism. BRI has a *call setup time* that is less than a second, and the 64-kbps B channel provides greater capacity than an analog modem link. If greater capacity is required, a second B channel can be activated to provide a total of 128 kbps. Although this is inadequate for video, it permits several simultaneous voice conversations in addition to data traffic.

Another common application of ISDN is to provide additional capacity as needed on a leased-line connection. The leased line is sized to carry average traffic loads, and ISDN is added during peak demand periods. ISDN is also used as a backup if the leased line fails. ISDN tariffs are based on a per-B-channel basis and are similar to those of analog voice connections.

With PRI ISDN, multiple B channels can be connected between two endpoints. This allows for videoconferencing and high-bandwidth data connections with no latency or jitter. However, multiple connections can be very expensive over long distances.

Note

Although ISDN is still an important technology for telephone service provider networks, it is declining in popularity as an Internet connection option with the introduction of high-speed DSL and other broadband services. The “Consumer and Industry Perspectives” section at <http://en.wikipedia.org/wiki/ISDN> provides a good discussion of ISDN worldwide trends.


Packet-Switched Connection Options

The most common packet-switching technologies used in today’s enterprise WANs include legacy X.25, Frame Relay, and ATM, as described in the following sections.

X.25

Figure 1-24 shows an X.25 network. X.25 is a legacy network-layer protocol that provides subscribers with a network address. Virtual circuits can be established through the network with call request packets to the target address. The resulting SVC is identified by a channel number. Data packets labeled with the channel number are delivered to the corresponding address. Multiple channels can be active on a single connection.

Figure 1-24 X.25 Network



Typical X.25 applications are point-of-sale card readers. These readers use X.25 in dialup mode to validate transactions on a central computer. For these applications, the low bandwidth and high latency are not a concern, and the low cost makes X.25 affordable.


X.25 link speeds vary from 2400 bps up to 2 Mbps. However, public networks usually are low-capacity, with speeds rarely exceeding 64 kbps.

X.25 networks are now in dramatic decline, being replaced by newer Layer 2 technologies such as Frame Relay, ATM, and ADSL. However, they are still in use in many portions of the developing world, which have limited access to newer technologies.

Frame Relay

Figure 1-25 shows a Frame Relay network. Although the network layout appears similar to X.25, Frame Relay differs from X.25 in several ways. Most importantly, it is a much simpler protocol, operating strictly at Layer 2, whereas X.25 additionally provides Layer 3 services. Frame Relay implements no error or flow control. The simplified handling of frames leads to reduced latency, and measures taken to avoid frame buildup at intermediate switches help reduce jitter. Frame Relay offers data rates up to 4 Mbps, with some providers offering even higher rates.

Figure 1-25 Frame Relay Network



Frame Relay VCs are uniquely identified by a DLCI, which ensures bidirectional communication from one DTE device to another. Most Frame Relay connections are PVCs rather than SVCs.


Frame Relay provides permanent, shared, medium-bandwidth connectivity that carries both voice and data traffic. Frame Relay is ideal for connecting enterprise LANs. The router on the LAN needs only a single interface, even when multiple VCs are used. The short-leased line to the Frame Relay network edge allows cost-effective connections between widely scattered LANs.

Frame Relay is described in more detail in Chapter 3.

ATM

Figure 1-26 shows an ATM network. Asynchronous Transfer Mode (ATM) technology can transfer voice, video, and data through private and public networks. It is built on a cell-based architecture rather than on a frame-based architecture. ATM cells are always a fixed length of 53 bytes. The ATM cell contains a 5-byte ATM header followed by 48 bytes of ATM payload. Small, fixed-length cells are well suited for carrying voice and video traffic, because this traffic is intolerant of delay. Video and voice traffic do not have to wait for a larger data packet to be transmitted.

Figure 1-26 ATM Network



The 53-byte ATM *cell* is less efficient than the bigger frames and packets of Frame Relay and X.25. Furthermore, the ATM cell has at least 5 bytes of overhead for each 48-byte payload. When the cell is carrying segmented network layer packets, the overhead is higher, because the ATM switch must be able to reassemble the packets at the destination. A typical ATM line needs almost 20 percent more bandwidth than Frame Relay to carry the same volume of network layer data.

ATM was designed to be extremely scalable. It can support link speeds of T1/E1 to OC-12 (622 Mbps) and higher.

ATM offers both PVCs and SVCs, although PVCs are more common with WANs. And as with other shared technologies, ATM allows multiple VCs on a single leased-line connection to the network edge.

Internet Connection Options


The Internet is an inexpensive and secure option for connecting to teleworkers and remote offices where performance guarantees are not critical.

Broadband connection options typically are used to connect telecommuting employees to a corporate site over the Internet. These options include DSL, cable, and wireless.

DSL

DSL technology, shown in Figure 1-27, is an always-on connection technology that uses existing twisted-pair telephone lines to transport high-bandwidth data and provides IP services to subscribers. A DSL modem converts an Ethernet signal from the user device into a DSL signal, which is transmitted to the central office.

Figure 1-27 DSL



Multiple DSL subscriber lines are multiplexed into a single high-capacity link using a DSL access multiplexer (DSLAM) at the provider location. DSLAMs incorporate TDM technology to aggregate many subscriber lines into a single medium, generally a T3 (DS3) connection. Current DSL technologies use sophisticated coding and modulation techniques to achieve data rates of up to 8.192 Mbps.


A wide variety of DSL types, standards, and emerging technologies exist. DSL is now a popular choice for enterprise IT departments to support home workers. Generally, a subscriber cannot choose to connect to an enterprise network directly. The subscriber must first connect to an ISP, and then an IP connection is made through the Internet to the enterprise. Security risks are incurred in this process, but they can be mediated with security measures.

Cable Modem

Coaxial cable is widely used in urban areas to distribute television signals. Network access is available from some *cable television* networks. This allows for greater bandwidth than the conventional telephone local loop.

Cable modems provide an always-on connection and a simple installation. Figure 1-28 shows how a subscriber connects a computer or LAN router to the cable modem, which translates the digital signals into the broadband frequencies used for transmitting on a cable television network. The local cable TV office, which is called the cable headend, contains the computer system and databases needed to provide Internet access. The most important component located at the *headend* is the cable modem termination system (CMTS). It sends and receives digital cable modem signals on a cable network and is necessary for providing Internet services to cable subscribers.

Figure 1-28 Cable Modem



Cable modem subscribers must use the ISP associated with the service provider. All the local subscribers share the same cable bandwidth. As more users join the service, available bandwidth may be below the expected rate.


Broadband Wireless

Wireless technology uses the unlicensed radio spectrum to send and receive data. The unlicensed spectrum is accessible to anyone who has a wireless router and wireless technology in the device he or she is using.

Until recently, one limitation of wireless access has been the need to be within the local transmission range (typically less than 100 feet) of a wireless router or a wireless modem that has a wired connection to the Internet. The following new developments in broadband wireless technology are changing this situation:

- **Municipal Wi-Fi:** Many cities have begun setting up municipal wireless networks. Some of these networks provide high-speed Internet access for free or for substantially less than the price of other broadband services. Others are for city use only, allowing police and fire departments and other city employees to do certain aspects of their jobs remotely. To connect to a municipal Wi-Fi, a subscriber typically needs a wireless modem, which provides a stronger radio and directional antenna than conventional wireless adapters. Most service providers provide the necessary equipment for free or for a fee, much like they do with DSL or cable modems.
- **WiMAX:** Worldwide Interoperability for *Microwave* Access (WiMAX) is a new technology that is just beginning to come into use. It is described in IEEE standard 802.16. WiMAX provides high-speed broadband service with wireless access and provides broad coverage like a cell phone network rather than through small Wi-Fi hotspots. WiMAX operates in a similar way to Wi-Fi, but at higher speeds, over greater distances, and for a greater number of users. It uses a network of WiMAX towers that are similar to cell phone towers, as shown in Figure 1-29. To access a WiMAX network, subscribers must subscribe to an ISP that has a WiMAX tower within 10 miles of their location. They also need a WiMAX-enabled computer and a special encryption code to get access to the base station.
- **Satellite Internet:** This is typically used by rural users where cable and DSL are unavailable. A satellite dish provides two-way (upload and download) data communications. The upload speed is about one-tenth of the 500-kbps download speed. Cable and DSL have higher download speeds, but satellite systems are about ten times faster than an analog modem. To access satellite Internet services, subscribers need a satellite dish, two modems (uplink and downlink), and coaxial cables between the dish and the modem.

Figure 1-29 Broadband Wireless



DSL, cable, and wireless broadband services are described in more detail in Chapter 6, “Teleworker Services.”

VPN Technology

Security risks are incurred when a teleworker or remote office uses broadband services to access the corporate WAN over the Internet. To address security concerns, broadband services provide capabilities for using Virtual Private Network (VPN) connections to a VPN server, which typically is located at the corporate site.

A VPN is an encrypted connection between private networks over a public network such as the Internet. Instead of using a dedicated Layer 2 connection such as a leased line, a VPN uses virtual connections called VPN tunnels, which are routed through the Internet from the company’s private network to the remote site or employee host.

VPN Benefits

Benefits of VPN include the following:

- **Cost savings:** VPNs enable organizations to use the global Internet to connect remote offices and remote users to the main corporate site, thus eliminating expensive dedicated WAN links and modem banks.
- **Security:** VPNs provide the highest level of security by using advanced encryption and authentication protocols that protect data from unauthorized access.

- **Scalability:** Because VPNs use the Internet infrastructure within ISPs and devices, it is easy to add new users. Corporations can add large amounts of capacity without adding significant infrastructure.
- **Compatibility with broadband technology:** VPN technology is supported by broadband service providers such as DSL and cable, so mobile workers and telecommuters can take advantage of their home high-speed Internet service to access their corporate networks. Business-grade, high-speed broadband connections can also provide a cost-effective solution for connecting remote offices.

Types of VPN Access

Two types of VPN access exist:

- **Site-to-site VPNs:** Site-to-site VPNs connect entire networks to each other. For example, they can connect a branch office network to a company headquarters network, as shown in Figure 1-30. Each site is equipped with a VPN gateway, such as a router, *fire-wall*, VPN concentrator, or security appliance. In the figure, a remote branch office uses a site-to-site VPN to connect with the corporate head office.
- **Remote-access VPNs:** Remote-access VPNs enable individual hosts, such as telecommuters, mobile users, and extranet consumers, to access a company network securely over the Internet, as shown in Figure 1-31. Each host typically has VPN client software loaded or uses a web-based client.

Figure 1-30 Site-to-Site VPNs





Figure 1-31 Remote-Access VPNs


Metro Ethernet

Metro Ethernet is a rapidly maturing networking technology that broadens Ethernet to the public networks run by telecommunications companies. IP-aware Ethernet switches enable service providers to offer enterprises converged voice, data, and video services such as IP telephony, video streaming, imaging, and data storage. Figure 1-32 shows that by extending Ethernet to the metropolitan area, companies can provide their remote offices with reliable access to applications and data on the corporate headquarters LAN.

Here are some benefits of Metro Ethernet:

- **Reduced expenses and administration:** Metro Ethernet provides a switched, high-bandwidth Layer 2 network that can manage data, voice, and video all on the same infrastructure. This characteristic increases bandwidth and eliminates expensive conversions to ATM and Frame Relay. The technology enables businesses to inexpensively connect numerous sites in a metropolitan area to each other and to the Internet.
- **Easy integration with existing networks:** Metro Ethernet connects easily to existing Ethernet LANs, reducing installation costs and time.
- **Enhanced business productivity:** Metro Ethernet enables businesses to take advantage of productivity-enhancing IP applications that are difficult to implement on TDM or Frame Relay networks, such as hosted IP communications, VoIP, and streaming and broadcast video.

Figure 1-32 Service Provider Metro Ethernet



Choosing a WAN Link Connection

Now that you have looked at the variety of WAN connection options, how do you choose the best technology to meet the requirements of a specific business? Table 1-2 compares the advantages and disadvantages of the WAN connection options that we have discussed in this chapter.

Table 1-2 Choosing a WAN Link Connection

Option	Description	Advantages	Disadvantages	Sample Protocols
Leased line	Point-to-point connection between two computers' LANs.	Most secure	Expensive	PPP, HDLC, SDLC
Circuit switching	A dedicated circuit path is created between endpoints. Best example is dialup connections.	Less expensive	Call setup	PPP, ISDN
Packet switching	Devices transport packets via a shared single point-to-point or point-to-multipoint link across a carrier inter network. Variable-length packets are transmitted over PVCs or SVCs.	Highly efficient use of bandwidth	Shared media across link	X.25, Frame Relay
Cell relay	Similar to packet switching, but uses fixed-length cells instead of variable-length packets. Data is divided into fixed-length cells and then transported across virtual circuits.	Best for simultaneous use of voice and data	Overhead can be considerable	ATM
Internet	Connectionless packet switching using the Internet as the WAN infrastructure. Uses network addressing to deliver packets. Because of security issues, VPN technology must be used.	Least expensive, globally available	Least secure	VPN, DSL, cable modem, wireless

This information is a good start. In addition, to help you in the decision-making process, the following sections list some questions to ask yourself when choosing a WAN connection option.

What Is the Purpose of the WAN?

Do you want to connect local branches in the same city area, connect remote branches, connect to a single branch, connect to customers, connect to business partners, or some combination of these? If the WAN is for providing authorized customers or business partners limited access to the company intranet, what is the best option?

What Is the Geographic Scope?

Is it local, regional, global, one-to-one (single branch), one-to-many branches, many-to-many (distributed)? Depending on the range, some WAN connection options may be better than others.

What Are the Traffic Requirements?

Traffic requirements to consider include the following:

- Traffic type (data only, VoIP, video, large files, streaming files) determines the quality and performance requirements. For example, if you are sending a lot of voice or streaming video traffic, ATM may be the best choice.
- Traffic volumes depending on type (voice, video, or data) for each destination determine the bandwidth capacity required for the WAN connection to the ISP.
- Quality requirements may limit your choices. If your traffic is highly sensitive to latency and jitter, you can eliminate any WAN connection options that cannot provide the required quality.
- Security requirements (data integrity, confidentiality, and security) are an important factor if the traffic is of a highly confidential nature or if provides essential services, such as emergency response.

Should the WAN Use a Private or Public Infrastructure?

A private infrastructure offers the best security and confidentiality, whereas the public Internet infrastructure offers the most flexibility and lowest ongoing expense. Your choice depends on the purpose of the WAN, the types of traffic it carries, and the available operating budget. For example, if the purpose is to provide a nearby branch with high-speed secure services, a private dedicated or switched connection may be best. If the purpose is to connect many remote offices, a public WAN using the Internet may be the best choice. For distributed operations, a combination of options may be the best solution.

For a Private WAN, Should It Be Dedicated or Switched?

Real-time, high-volume transactions have special requirements that could favor a dedicated line, such as traffic flowing between the data center and the corporate head office. If you are connecting to a local single branch, you could use a dedicated leased line. However, that

option would become very expensive for a WAN connecting multiple offices. In that case, a switched connection might be better.

For a Public WAN, What Type of VPN Access Do You Need?

If the purpose of the WAN is to connect a remote office, a site-to-site VPN may be the best choice. To connect teleworkers or customers, remote-access VPNs are a better option. If the WAN is serving a mixture of remote offices, teleworkers, and authorized customers, such as a global company with distributed operations, a combination of VPN options may be required.

Which Connection Options Are Available Locally?

In some areas, not all WAN connection options are available. In this case, your selection process is simplified, although the resulting WAN may provide less-than-optimal performance. For example, in a rural or remote area, the only option may be broadband satellite Internet access.

What Is the Cost of the Available Connection Options?

Depending on the option you choose, the WAN can be a significant ongoing expense. The cost of a particular option must be weighed against how well it meets your other requirements. For example, a dedicated leased line is the most expensive option, but the expense may be justified if it is critical to ensure secure transmission of high volumes of real-time data. For less-demanding applications, a cheaper switched or Internet connection option may be more suitable. Also, wireless point-to-point bridges are becoming a potential alternative to leased lines.

As you can see, you must consider many important factors when choosing an appropriate WAN connection. Following the guidelines just described, as well as those described by the Cisco Enterprise Architecture, you should now be able to choose an appropriate WAN connection to meet the requirements of different business scenarios.

Summary

A WAN is a data communications network that operates beyond the geographic scope of a LAN.

As companies grow, adding more employees, opening branch offices, and expanding into global markets, their requirements for integrated services change. These business requirements drive companies' network requirements.

The Cisco Enterprise Architecture expands on the Hierarchical Network Model by further dividing the enterprise network into physical, logical, and functional areas.

Implementing a Cisco Enterprise Architecture provides a secure, robust network with high availability that facilitates the deployment of converged networks.

WANs operate in relation to the OSI reference model, primarily on Layers 1 and 2.

Devices that put data on the local loop are called data circuit-terminating equipment or data communications equipment (DCE). The customer devices that pass the data to the DCE are called data terminal equipment (DTE). The DCE primarily provides an interface for the DTE into the communication link on the WAN cloud.

The physical demarcation point is the place where the responsibility for the connection changes from the enterprise to the service provider.

Data link layer protocols define how data is encapsulated for transmission to remote sites and the mechanisms for transferring the resulting frames.

A circuit-switching network establishes a dedicated circuit (or channel) between nodes and terminals before the users may communicate.

A packet-switching network splits traffic data into packets that are routed over a shared network. Packet-switching networks do not require a circuit to be established and allow many pairs of nodes to communicate over the same channel.

A point-to-point link provides a preestablished WAN communications path from the customer premises through the provider network to a remote destination. Point-to-point links use leased lines to provide a dedicated connection.

Circuit-switching WAN options include analog dialup and ISDN. Packet-switching WAN options include X.25, Frame Relay, and ATM. ATM transmits data in 53-byte cells rather than frames. ATM is best suited to video traffic.

Internet WAN connection options include broadband services, such as DSL, cable modem or broadband wireless, and Metro Ethernet. VPN technology enables businesses to provide secure teleworker access through the Internet over broadband services.

Labs

The activities and labs available in the companion *Accessing the WAN, CCNA Exploration Labs and Study Guide* (ISBN 1-58713-212-5) provide hands-on practice with the following topic introduced in this chapter:



Lab 1-1: Challenge Review (1.4.1)

In this lab, you review basic routing and switching concepts. Try to do as much on your own as possible. Refer to previous material when you cannot proceed on your own.

Note

Configuring three separate routing protocols—RIP, OSPF, and EIGRP—to route the same network definitely is not a best practice. It should be considered a *worst* practice and is not something that would be done in a production network. It is done here so that you can review the major routing protocols before proceeding and see a dramatic illustration of the concept of administrative distance.



Many of the Hands-on Labs include Packet Tracer Companion Activities, where you can use Packet Tracer to complete a simulation of the lab. Look for this icon in *Accessing the WAN, CCNA Exploration Labs and Study Guide* for Hands-on Labs that have a Packet Tracer Companion.

Check Your Understanding

Complete all the review questions listed here to test your understanding of the topics and concepts in this chapter. Answers are listed in Appendix, “Check Your Understanding and Challenge Questions Answer Key.”

1. Which of the following items are considered WAN devices? (Choose three.)
 - A. Bridge
 - B. Modem
 - C. Router
 - D. Ethernet switch
 - E. Access server
 - F. Repeater
2. Which layer of the hierarchical network design model is often called the backbone?
 - A. Access
 - B. Distribution
 - C. Network
 - D. Core
 - E. Workgroup
 - F. WAN
3. Match each term with its definition:
 - Circuit switching
 - Packet switching
 - Connection-oriented packet switching
 - Connectionless packet switching
 - A. A switching technology in which each switch must evaluate the packet’s address to determine where to send it.
 - B. A switching technology in which a virtual circuit exists only while a packet travels through it.
 - C. A switching technology that establishes routes through the switches for particular end-to-end connections.
 - D. A switching technology that has a preestablished dedicated circuit (or channel) between nodes and terminals.

4. Match each term with its packet-switched technology definition:

Metro Ethernet

X.25

ATM

Frame Relay

- A. Provides a high-bandwidth Layer 2 network that can manage data, voice, and video all on the same infrastructure.
- B. Built on a cell-based architecture in which the cell has a fixed length of 53 bytes.
- C. Operates at the data link layer, and the PVC is identified by a Data Link Control Identifier.
- D. Operates at the network layer, and the SVC is identified by a channel number.

5. Which device is commonly used as Data Terminal Equipment?

- A. ISDN
- B. Modem
- C. Router
- D. CSU/DSU

6. Which type of WAN connection should you choose when a dedicated point-to-point WAN communications path from the customer premises through the provider network to a remote destination is required?

- A. ISDN
- B. Analog dialup
- C. ATM
- D. Frame Relay
- E. Leased line

7. How are Frame Relay virtual circuits identified?

- A. CIR
- B. DLCI
- C. VPI
- D. MAC
- E. SPID

8. What WAN technology is designed to deliver data, voice, and video simultaneously built on a cell-based architecture?
 - A. ATM
 - B. Cable
 - C. Frame Relay
 - D. ISDN

9. Which architecture enables enterprises to offer important network services—such as security, new communication services, and improved application performance—to every office, regardless of its size or proximity to headquarters?
 - A. Cisco Enterprise Campus Architecture
 - B. Cisco Enterprise Data Center Architecture
 - C. Cisco Enterprise Branch Architecture
 - D. Cisco Enterprise Teleworker Architecture

10. At which layer of the hierarchical network model do users connect to the network?
 - A. Application
 - B. Access
 - C. Distribution
 - D. Network
 - E. Core

11. ISDN PRI is composed of how many B channels in North America?
 - A. 2
 - B. 16
 - C. 23
 - D. 30
 - E. 64

12. The ability to connect securely to a private network over a public network is provided by which WAN technology?
 - A. DSL
 - B. Frame Relay
 - C. ISDN
 - D. PSTN
 - E. VPN

13. Which hierarchical network model layer is responsible for containing network problems to the workgroups in which they occur?
 - A. Application
 - B. Access
 - C. Distribution
 - D. Network
 - E. Core
14. What term describes the cabling that connects the customer site to the nearest exchange of the WAN service provider?
 - A. CPE
 - B. CO
 - C. Local loop
 - D. DCE
 - E. DTE
15. Which goal can be accomplished by implementing the Cisco Enterprise Teleworker Architecture?
 - A. It allows the enterprise to add large branch sites that span geographic areas.
 - B. It allows the enterprise to deliver secure voice and data services to workers no matter where or when they work.
 - C. To reduce remote security threats, it forces users who are located at main sites to log on to resources.
 - D. It satisfies telephony requirements for users who are located at medium to large enterprise sites.
16. Describe the three layers of the hierarchical network model.
17. Describe the five modules of the Cisco Enterprise Architecture.
18. Compare and contrast the following WAN terms: CPE, CO, local loop, DCE, DTE, and demarcation point.
19. Compare and contrast the following WAN devices: modem, CSU/DSU, access server, WAN switch, and router.
20. Compare and contrast X.25, Frame Relay, and ATM.

Challenge Questions and Activities

1. Explain the advantages and disadvantages of circuit-switched networks.
2. What are the differences between a site-to-site VPN and a remote-access VPN?